



Pronto changeable marquis letters are screenprinted on rigid plastic panels. They are .080" thick (about the thickness of a nickel). They are not flexible and are not bent when installed.

Pronto letters and Wagner ZipChange letters are interchangeable, as are the letter tracks and other accessories for both brands.

The letters in the picture at the right are about the thickness of a credit card (or less). They are called flex letters, and are common on portable arrow signs. They are far more easily blown out of the sign on windy days. These track and letters are not suited for Pronto or Wagner ZipChange systems.



The drawings on this page are not to scale.

The visible space (see right) between top and bottom letter tracks should be 5/8" less than the overall height of the letter panel.



This is true even when dual track is used for multiple lines of letters, as in the illustration at the far right.

Sign companies use wood blocks or other spacers cut the same size as the required visible opening space. They make it easier to keep the track the right distance apart over the length of the sign.

Once the tracks are aligned and securely taped in place, the easiest way to fasten them to the sign face is with special nylon rivets every 8" along the tracks.



These rivets can be used on sign faces from 1/8" to 3/16" thick. They are inserted into holes drilled (7/32" bit) through the track and sign face, and the heads are pushed in to lock them in place.

**Pronto Letter Track can be used in two different ways.**

The illustration at the left shows how top and bottom tracks are used for separate lines of letters.

The illustration at the right shows how dual track is used between top and bottom tracks. This method saves vertical space and is less expensive.

**Changing Pronto or Wagner Zip Change letters is done manually, or with a change arm/suction cup assembly if the sign is high.**

1. Top of letter panel is slid up under top track far enough that it clears the bottom track.



2. Letter panel then drops into position to rest in the bottom track.

3. Reverse the instructions to remove letters.

**Aztec Signs is an authorized distributor of Pronto letters & accessories, & other products of Gemini Inc.**

